



# Häfele Wireless Wall Switch

Connect Mesh 4-button remote and wall plate kit



- > Complete 4-Button remote kit in white
- > Each button can be programmed with the Häfele Connect Mesh App to control a group of lights or to activate a specific scenes.
- > The wireless Decora style wall switch is a great way to control pre-set scenes.
- > Clean and contemporary appearance
- > Smooth dimming control
- > Last setting stored when turned back on
- > Can be installed directly on a wall surface or over a wall box.
- > Includes Decora style wall plate and required wall mounting hardware as well as a CR2032 (002.99.032) battery.
- > Works with 12V and 24V MESH distributors to be ordered separately.

Description	Item No.
4-Button remote switch kit with wall plate, bracket and battery	450.80.868